



STEP 1:  
Lift pull head to a height of 300mm



STEP 2:  
Disconnect sliding sleeve by xxxxxx

300mm Lift and  
Disconnect Coupling



YLSand A&R Wire

FPSO Winch Wire

ROV

Riser

40 metres

Pull Head & FPSO Wire